

# Chapter 6

## Population Growth, Land Cover Changes and Water Quality

### 6.1 General Sources of Pollution

Human activities can negatively impact surface water quality, even when the activity is far removed from the waterbody. With proper management of wastes and land use activities, these impacts can be minimized. Pollutants that enter waters fall into two general categories: *point sources* and *nonpoint sources*.

#### *Point Sources*

Piped discharges from:

- Municipal wastewater treatment plants
- Industrial facilities
- Small package treatment plants
- Large urban and industrial stormwater systems

Point sources are typically piped discharges and are controlled through regulatory programs administered by the state. All regulated point source discharges in North Carolina must apply for and obtain a National Pollutant Discharge Elimination System (NPDES) permit from the state.

Nonpoint sources are from a broad range of land use activities. Nonpoint source pollutants are typically carried to waters by rainfall, runoff or snowmelt. Sediment and nutrients are most often associated with nonpoint source pollution. Other pollutants associated with nonpoint source pollution include fecal coliform bacteria, heavy metals, oil and grease, and any other substance that may be washed off the ground or deposited from the atmosphere into surface waters.

#### *Nonpoint Sources*

- Construction activities
- Roads, parking lots and rooftops
- Agriculture
- Failing septic systems and straight pipes
- Timber harvesting
- Hydrologic modifications

Unlike point source pollution, nonpoint pollution sources are diffuse in nature and occur intermittently, depending on rainfall events and

land disturbance. Given these characteristics, it is difficult and resource intensive to quantify nonpoint contributions to water quality degradation in a given watershed. While nonpoint source pollution control often relies on voluntary actions, the state has many programs designed to reduce nonpoint source pollution. For more information on nonpoint source pollution visit <http://h2o.enr.state.nc.us/nps/>.

#### *Cumulative Effects*

While any one activity may not have a dramatic effect on water quality, the cumulative effect of land use activities in a watershed can have a severe and long-lasting impact.

Every person living in or visiting a watershed contributes to impacts on water quality. Therefore, each individual should be aware of these contributions and take actions to reduce them.

## **6.2 Managing the Impacts of Growth and Development and Stormwater Runoff**

### **6.2.1 Introduction to Stormwater Runoff**

Stormwater runoff is rainfall or snowmelt that runs off the ground or impervious surface (i.e., buildings, roads, parking lots). In some cases, it drains directly into streams, rivers, lakes and oceans. In others, particularly urbanized areas, stormwater drains into streets and manmade drainage systems consisting of inlets and underground pipes, commonly referred to as a storm sewer system. Storm sewer systems are designed simply to capture the stormwater and convey it to the nearest surface waterbody. These sewers should not be confused with sanitary sewers, which transport human and industrial wastewaters to a treatment plant before discharging into surface waters.

Common stormwater pollutants include sediment, nutrients, organic matter, bacteria, oil and grease, and toxic substances (i.e., metals, pesticides, herbicides, hydrocarbons). Stormwater can also impact the temperature of a surface waterbody, which can affect the water's ability to support certain fish and aquatic communities.

Uncontrolled stormwater runoff has many impacts on both humans and the environment. Cumulative effects include flooding, undercut and eroding streambanks, widened stream channels, threats to public health and safety, impaired recreational use, and increased costs for drinking and wastewater treatment. For more information on stormwater runoff, visit the DWQ Stormwater Permitting Unit at <http://h2o.enr.state.nc.us/su/stormwater.html> or the NC Stormwater information page at <http://www.ncstormwater.org/>. Additional fact sheets and information can also be found at [http://www.stormwatercenter.net/intro\\_factsheets.htm](http://www.stormwatercenter.net/intro_factsheets.htm) and [www.bae.ncsu.edu/stormwater/index.html](http://www.bae.ncsu.edu/stormwater/index.html).

### **6.2.2 Effects of Growth and Development**

Urban growth poses one of the greatest threats to aquatic resources more than any other human activity. Greater numbers of homes, stores and businesses require greater quantities of water. Growing populations not only require more water, but they also lead to the discharge and runoff of greater quantities of waste and pollutants into the state's streams and groundwater. Thus, just as demand and use increases, some of the potential water supply is also lost (Orr and Stuart, 2000).

As development in surrounding metropolitan areas consumes neighboring forests and fields, the impacts on rivers, lakes and streams can be significant and permanent if stormwater runoff is not controlled (Orr and Stuart, 2000). As watershed vegetation is replaced with impervious surfaces in the form of paved roads, buildings, parking lots and residential homes and driveways, the ability of the environment to absorb and diffuse the effects of natural rainfall is diminished. Urbanization results in increased surface runoff and correspondingly earlier and higher peak streamflows after rainfall. Flooding frequency also increases. These effects are compounded when small streams are channelized (straightened) or piped, and storm sewer systems are installed to increase transport of stormwater downstream. Bank scour from these frequent high flow events tends to enlarge urban streams and increase suspended sediment. Scouring also

destroys the variety of habitat in streams, leading to degradation of benthic macroinvertebrate populations and loss of fisheries (EPA, 1999).

Based on the 2000 Census, the overall population of the New River basin is 49,653. This number is estimated based on the percent of the county land area that is partially or entirely contained within the New River basin. Although counties in the New River basin are not among the fastest growing counties in the state, the effects of development are impacting water quality. Two of the three counties in the basin experienced growth rates in excess of ten percent during the last decade of the 20<sup>th</sup> century. The sparsely developed watersheds of the north and western portions of the basin generally contain streams with high water quality, excellent aquatic communities and species populations, and are considered Supporting based on current use support methodologies. Impacts are quickly noted, however, in the southern and central watersheds where urbanization is focused around city centers and interstate corridors. It is no surprise then that the greatest concentration of streams with noted impacts lie in the areas of Boone and Blowing Rock. Between 1990 and 2000, Jefferson and West Jefferson also experienced increasing populations, and impacted waters are also found in these areas. As the counties in the New River basin continue to grow, there will likely be a loss of natural areas and an increase in the amount of impervious surface associated with new homes and businesses.

The New River basin has an abundance of surface water that has supported the current domestic expansion in the urban areas. Even today, there is sufficient water to serve its diverse domestic, agricultural, energy and recreational needs except in periods of severe drought. It is those periods of drought that point to the impending threats of the availability of good quality water. Clean water can likely be provided in sufficient quantity to supply the future needs of the basin, but only with inspired foresight, planning and management. For more information on county population density, refer to Appendix I. Appendix II lists local governments and Appendix III provides information related to land cover changes.

### **6.2.3 Controlling Stormwater Pollution**

Many daily activities have the potential to cause stormwater pollution. Any situation where activities can contribute more pollutants to stormwater runoff is an area that should be considered for efforts to minimize stormwater impacts. A major component in reducing stormwater impacts involves planning up front in the design process. New construction designs should include plans to prevent or minimize the amount of runoff leaving the site. Wide streets, large cul-de-sacs, long driveways and sidewalks lining both sides of the street are all features of urban development that create excess impervious cover and consume natural areas. In many instances, the presence of intact riparian buffers and/or wetlands in urban areas can reduce the impacts of urban development. Establishment and protection of buffers should be considered where feasible, and the amount of impervious cover should be limited as much as possible.

“Good housekeeping” to reduce the volume of stormwater leaving a site and reducing the amount of pollutants used in our own backyards can also minimize the impact of stormwater runoff. DWQ has published a pamphlet entitled *Improving Water Quality in Your Own Backyard: Stormwater Management Starts at Home*. The pamphlet provides information on how homeowners and businesses can reduce the amount of runoff leaving their property and how to reduce the amount and types of pollutants in that runoff. This document is available on-line at <http://h2o.enr.state.nc.us/nps/documents/BackyardPDF.pdf> or by calling (919) 733-5083.

Preserving the natural streamside vegetation (riparian buffer) is one of the most economical and efficient BMPs. In particular, forested buffers provide a variety of benefits including filtering runoff and taking up nutrients, moderating water temperature, preventing erosion and loss of land, providing flood control and helping to moderate streamflow, and providing food and habitat for both aquatic and terrestrial wildlife (NCDENR-DWQ, February 2004). For more information or to obtain a free copy of DWQ's *Buffers for Clean Water* brochure, call (919) 733-5083, ext. 558.

#### 6.2.4 Protecting Headwaters

Many streams in a given river basin are only small trickles of water that emerge from the ground. A larger stream is formed at the confluence of these trickles (Figure 13). This constant merging eventually forms a large stream or river. Most monitoring of fresh surface waters evaluates these larger streams. The many miles of small trickles, collectively known as headwaters, are not directly monitored and in many instances are not even indicated on maps. These streams account for approximately 80 percent of the stream network and provide many valuable services for quality and quantity of water delivered downstream (Meyer *et al.*, 2003). However, degradation of headwater streams can (and does) impact the larger stream or river.




Figure 13 Diagram of Headwater Streams within a Watershed Boundary

There are three types of headwater streams: 1) perennial (flow year-round); 2) intermittent (flow during wet seasons); and 3) ephemeral (flow only after precipitation events). All types of headwater streams provide benefits to larger streams and rivers. Headwater streams control flooding, recharge groundwater, maintain water quality, reduce downstream sedimentation, recycle nutrients and create habitat for plants and animals (Meyer *et al.*, 2003).

In smaller headwater streams, fish communities are not well developed and benthic macroinvertebrates dominate aquatic life. Benthic macroinvertebrates are often thought of as "fish food" and, in mid-sized streams and rivers, they are critical to a healthy fish community. However, these insects, both in larval and adult stages, are also food for small mammals, such as

river otter and raccoons, birds and amphibians (Erman, 1996). Benthic macroinvertebrates in headwater streams also perform the important function of breaking down coarse organic matter, such as leaves and twigs, and releasing fine organic matter. In larger rivers, where coarse organic matter is not as abundant, this fine organic matter is a primary food source for benthic macroinvertebrates and other organisms in the system (CALFED, 1999). When the benthic macroinvertebrate community is changed or extinguished in an area, even temporarily, as occurs during land use changes, it can have repercussions in many parts of both the terrestrial and aquatic food web.

Headwater streams also provide a source of insects for repopulating downstream waters where benthic macroinvertebrate communities have been eliminated due to human alterations and pollution. Adult insects have short life spans and generally live in the riparian areas surrounding the streams from which they emerge (Erman, 1996). Because there is little upstream or stream-to-stream migration of benthic macroinvertebrates, once headwater populations are eliminated, there is little hope for restoring a functioning aquatic community. In addition to macroinvertebrates, these streams support diverse populations of plants and animals that face similar problems if streams are disturbed. Headwater streams are able to provide these important ecosystem services due to their unique locations, distinctive flow patterns and small drainage areas.

Because of the small size of headwater streams, they are often overlooked during land use activities that impact water quality. All landowners can participate in the protection of headwaters by keeping small tributaries in mind when making land use management decisions on the areas they control. This includes activities such as retaining vegetated stream buffers, minimizing stream channel alterations and excluding cattle from streams. Local rural and urban planning initiatives should also consider impacts to headwater streams when land is being developed. For a more detailed description of watershed hydrology and watershed management, refer to EPA's Watershed Academy website at <http://www.epa.gov/OWOW/watershed/wacademy/acad2000/watershedmgt/principle1.html>.

## **6.3 The Role of Local Governments**

### **6.3.1 Introduction and Overview**

Below is a summary of management actions recommended for local authorities, followed by discussions on large, watershed management issues. These actions are necessary to address current sources of impairment and to prevent future degradation in all streams. The intent of these recommendations is to describe the types of actions necessary to improve stream conditions, not to specify particular administrative or institutional mechanisms for implementing remedial practices. Those types of decisions must be made at the local level.

Because of uncertainties regarding how individual remedial actions cumulatively impact stream conditions and in how aquatic organisms will respond to improvements, the intensity of management effort necessary to bring about a particular degree of biological improvement cannot be established in advance. The types of actions needed to improve biological conditions can be identified, but the mix of activities that will be necessary – and the extent of improvement that will be attainable – will only become apparent over time as an adaptive management

approach is implemented. Management actions are suggested below to address individual problems, but many of these actions are interrelated.

Actions one through five are important to restoring and sustaining aquatic communities in the watershed, with the first three recommendations being the most important.

**(1) Feasible and cost-effective stormwater retrofit projects should be implemented throughout the watershed to mitigate the hydrologic effects of development** (i.e., increased stormwater volumes and increased frequency and duration of erosive and scouring flows). This should be viewed as a long-term process. Although there are many uncertainties, costs in the range of \$1 million per square mile can probably be anticipated.

- (a) Over the short term, currently feasible retrofit projects should be identified and implemented.
- (b) In the long term, additional retrofit opportunities should be implemented in conjunction with infrastructure improvements and redevelopment of existing developed areas.
- (c) Grant funds for these retrofit projects may be available from EPA initiatives such as EPA Section 319 or the North Carolina Clean Water Management Trust Fund (CWMTF).

**(2) A watershed scale strategy to address toxic inputs should be developed and implemented, including a variety of source reduction and stormwater treatment methods.** As an initial framework for planning toxicity reduction efforts, the following general approach is proposed:

- (a) Implementation of available best management practice (BMP) opportunities for control of stormwater volume and velocities. As recommended above to improve aquatic habitat potential, these BMPs will also remove toxics from stormwater.
- (b) Development of a stormwater and dry weather sampling strategy in order to facilitate the targeting of pollutant removal and source reduction practices.
- (c) Implementation of stormwater treatment BMPs, aimed primarily at pollutant removal, at appropriate locations.
- (d) Development and implementation of a broad set of source reduction activities focused on: reducing nonstorm inputs of toxics; reducing pollutants available for runoff during storms; and managing water to reduce stormwater runoff.

**(3) Stream channel restoration activities should be implemented in target areas, in conjunction with stormwater retrofit BMPs, in order to improve aquatic habitat.** Before beginning stream channel restoration, a geomorphologic survey should be conducted to determine the best areas for stream channel restoration. Additionally, it would be advantageous to implement retrofit BMPs before embarking on stream channel restoration, as restoration is best designed for flows driven by reduced stormwater runoff. Costs of approximately \$200 per foot of channel should be anticipated (Haupt, *et al.*, 2002 and Weinkam *et al.*, October 2001). Grant funds for these retrofit projects may be available from federal sources such as EPA Section 319 or state sources including North Carolina CWMTF.

- (4) Actions recommended above (i.e., stormwater quantity and quality retrofit BMPs) are likely to reduce nutrient/organic loading, and to some extent, its impacts. Activities recommended to address this loading include the identification and elimination of illicit discharges; education of homeowners, commercial applicators, and others regarding proper fertilizer use; street sweeping; catch basin clean-out practices; and the installation of additional BMPs targeting biological oxygen demand (BOD) and nutrient removal at appropriate sites.
- (5) Prevention of further channel erosion and habitat degradation will require effective post-construction stormwater management for all new development in the study area.
- (6) Effective enforcement of sediment and erosion control regulations will be essential to the prevention of additional sediment inputs from construction activities. Development of improved erosion and sediment control practices may also be beneficial.
- (7) Watershed education programs should be implemented and continued by local governments with the goal of reducing current stream damage and preventing future degradation. At a minimum, the program should include elements to address the following issues:
  - (a) Redirecting downspouts to pervious areas rather than routing these flows to driveways or gutters.
  - (b) Protecting existing woody riparian areas on all streams.
  - (c) Replanting native riparian vegetation on stream channels where such vegetation is absent.
  - (d) Reducing and properly managing pesticide and fertilizer use.

### **6.3.2 Reducing Impacts of Future Development**

Proactive planning efforts at the local level are needed to assure that development is done in a manner that maintains water quality. These planning efforts will need to find a balance between water quality protection, natural resource management and economic growth. Growth management requires planning for the needs of future population increases as well as developing and enforcing environmental protection measures. These actions are critical to water quality management and the quality of life for the residents of the basin.

Areas adjacent to the high growth areas of the basin are at risk of having Impaired biological communities. These biological communities are important to maintaining the ecological integrity in the New River basin. These streams will be important as sources of benthic macroinvertebrates and fish for reestablishment of biological communities in nearby streams that are recovering from past impacts or are being restored.

To prevent further impairment to aquatic life in streams in urbanizing watersheds local governments should:

- (1) Identify waters that are threatened by development.
- (2) Protect existing riparian habitat along streams.
- (3) Implement stormwater BMPs during and after development.
- (4) Develop land use plans that minimize disturbance in sensitive areas of watersheds.

- (5) Minimize impervious surfaces including roads and parking lots.
- (6) Develop public outreach programs to educate citizens about stormwater runoff.

Action needs be taken at the local level to plan for new development in urban and rural areas. For more detailed information regarding recommendations for new development found in the text box (above), refer to EPA’s website at [www.epa.gov/owow/watershed/wacademy/acad2000/protection](http://www.epa.gov/owow/watershed/wacademy/acad2000/protection), the Center for Watershed Protection website at [www.cwp.org](http://www.cwp.org), and the Low Impact Development Center website at [www.lowimpactdevelopment.org](http://www.lowimpactdevelopment.org). Additional public education is also needed in the New River basin in order for citizens to understand the value of urban planning and stormwater management. For an example of local community planning efforts to reduce stormwater runoff, visit <http://www.charmeck.org/Home.htm>.

*Planning Recommendations  
for New Development*

- Minimize number and width of residential streets.
- Minimize size of parking areas (angled parking & narrower slots).
- Place sidewalks on only one side of residential streets.
- Minimize culvert pipe and hardened stormwater conveyances.
- Vegetate road right-of-ways, parking lot islands and highway dividers to increase infiltration.
- Plant and protect natural buffer zones along streams and tributaries.

### **6.3.3 Existing Programs to Control Stormwater Runoff**

In North Carolina, there are a number of programs directly tied to the management and control of stormwater runoff from new development activities near sensitive waters. These sensitive waters include:

- Water Supply Watersheds
- High Quality Waters (HQW)
- Outstanding Resource Waters (ORW)
- Nutrient Sensitive Waters

There is also a federal program that requires stormwater permits for point source dischargers of stormwater from certain industrial activities and from large municipalities. For more information on stormwater programs across the state, refer to Chapter 7.